

In-line Milk Analysis: Key in Daily **Dairy Farm Management Decisions**



afimilk, Afikim, Israel



- Milk in a dairy cow reflects its physiological condition
- ➤ AfiLab™ measures milk composition for each cow, during every milking
- ➤ AfiLab™ data reveals metabolic disorders and feeding alterations, accordingly response time is shortened and damage reduced









Utilizing AfiLab Milk Component Data

✓ Monitoring energy balance statuses

✓ Nutrition monitoring & precision feeding

√ Udder health & Milk quality



Monitoring EB status - Herd Health and Fertility Management

- Early diagnosis and treatment of ketosis
- ✓ Improving of lactation curves
- ✓ Competence for insemination and pregnancy
- ✓ Health monitoring along pregnancy



Decades of Genetic Improvements and Selection...



Milk production is the cow's top priority


Feed intake < Energy requirements



Negative energy balance (NEB)










Ketosis & Milk Fat-to-Protein Ratio Relations

The differences (180 days yield) between Ketotic and non Ketotic cows

9679 ketosis events out of 42355 lactations





Ketosis & Milk Fat-to-Protein Ratio Relations

180 days milk yield loss (kg) for various risk factors compared to cows with "no factor"


300,000 (>2nd) lactations of 160,000 cows (2002 - 2010)



dystocia FPR>1.4 ketosis uterine (17%) (13%) disease




Different Patterns of Herd Energy Status






Time Differences Between BHBA and FPR





Blood Ketone Changes During a Day



Manual cow-side ketone tests as part of routine postpartum examination?

- 0
- □ Different herds have different metabolic patterns
- □ Ketone levels in different body fluids increase at different times
- No definite time for effective ketone measurement during the day
- ☐ Costly and requires manual labor
- Additional stress for postpartum cows



Diagnosing Ketosis Using AfiLab Data

- ☐ 4 field trials (commercial dairy farms 700-900 cows)
- □ cows were tested 4 times a week for ketosis (rates were 14-38%)
- □"gold standard" > Serum BHBA >1.4 mmol/L

Model	Fat/protein ratio	Sensitivity	Specificity
Α	High	55%	85%
В	Low	85%	55%





Index	Cow	Lact. no.	Grp.	DIM	Fat/Protein		
					1	2	3
1	6275	5	3	4		1.34	1.30
2	6374	4	3	16	1.60	1.85	1.56
3	6376	4	2	29	1.18	1.40	1.16
4	6397	4	3	37		1.69	1.44
5	6494	4	2	11	1.63	1.76	1.65
6	6585	3	3	40	1.12	1.40	1.23
7	6596	3	3	10	1.37	1.66	1.48
8	6616	3	3	16		1.40	1.22
9	6637	3	2	27	1.24	1.78	1.24
10	6655	2	٦	21	1.07	1.44	1.26
11	6664	2	1	31	1.07	1.41	1.08
12	6704	2	1	18	1.49	1.75	1.62
13	6769	2	1	28	0.99	1.40	1.21
14	6776	2	1	4	1.35	1.21	1.13
15	6777	2	1	15	1.50	1.71	1.93
16	6916	1	4	9		1.38	1.48
17	6977	1	4	10	1.77	1.84	1.64
18	6984	1	4	5	1.31	1.08	1.36
Avg.				18	1.34	1.53	1.39

Using this combined model farmers get a daily list of cows (5-45 DIM) to treat for ketosis

























Cow 919 is suffering from ketosis according to AfiLab almost from calving time

Milk ■ Fat/protein ■

Milk: 61340



Daily Milk Composition Used for Feeding Monitoring & Management

- ✓ Precision feeding
- **✓** Simple Indigestion
- √ Sub-acute rumen acidosis (SARA)





Feeding Control 23/02/2013 (24/02/2013 10:25:19)





🔁 Station tree 🛮 🔐 Recommendations 🗡 Recalculate





1 Parameters



Unbalanced Feeding Ration

Low Fat



Fat Decrease



Protein Decrease



SARA Suspicion - Day



SARA Suspicion - Session





Effect of Precision Feeding on Performance, Nutrient Excretion and Feeding Behavior of Early Lactation Dairy Cows

Conclusions: Allocating concentrates according to the needs of the cows improved lactation performance and efficiency of DM conversion compared with feeding a single TMR

Ephraim Maltz et al.












→ Other

Using AfiLab Data to Detect Clinical Mastitis

Daily milk lactose concentrations (%) of case and controls



afimilk

Summary



Each herd has its own internal truth

- Preventing excessive body fat loss is key for optimal transitions to improved production and fertility performance
- Understanding physiological changes provides a basis for management strategies
- AfiLab real time milk analyzer takes dairy herd management to the next level
- Its abundance of data and immediate availability opens new territories in dairy herd management, territories we are exploring vigorously and determinedly

Thank you!





















