An overview of wished recording requirements to satisfy to the current evolution of milk recording organizations and selection programs in France

H.Leclerc, X.Bourrigan & G.Augier

CONSEIL ÉLEVAGE Donner du sens à la mesure



www.idele.fr ICAR 39th Biennial Session - Berlin, Germany (19 - 23 May, 2014)

Aims of the presentation

Present the context of Milk Recording in France and the requests for changes (flexibility, cost,...)

Summarize 3 studies realised between 2003 & 2013 and show how it meets the needs of evolution to maintain a high level of quality

Propose evolution of ICAR guidelines on milking schemes



2

A PARA

Definition of 8 milking schemes in France

A : supervised 24 hours milking

ALTER ALTER

- AT: supervised alternative milking
- B : unsupervised 24 hours milking
- BT: unsupervised alternative milking
- AR: supervised 24 hours robotic milking
- BR: unsupervised 24 hours robotic milking
- CZ: supervised / unsupervised 24 hours (sampling one milking)
- BZ: unsupervised 24 hours with sampling one milking





Donner du sens à la mesur

Evolution of the penetration rate, herd size, milking schemes in France

Year	Penetration rate	Herd size	% of dairy herds recorded according to milking schemes					
			А	AT - BT	В	AR - BR	CZ - BZ	
2003	66 %	40.4	90.1 %	9.8 %	/	0.1 %	/	
2005	68 %	41.5	85.5 %	13.6 %	/	0.9 %	/	
2007	66 %	41.5	78.4 %	16.7 %	2.3 %	1.0 %	1.6 %	
2009	68 %	46.1	73.2 %	17.8 %	3.6 %	2.9 %	2.5 %	
2011	69 %	48.1	68.2 %	18.9 %	5.6 %	4.6 %	2.7 %	
2013	69 %	52.1	65.6 %	19.0 %	6.0 %	6.7 %	2.7 %	
	=	7	И	7	7	Я	7	

INSTITUT DE

FRANCE CONSEIL ÉLEVAGE Donner du sens à la mesure

www.idele.fr ICAR 39th Biennial Session - Berlin, Germany (19 - 23 May, 2014)

The environment is changing...

Evolution of the number of farms equipped with AMS in France



+ 300 to 400 AMS per year in France

MARTIN ASTRO

www.idele.fr ICAR 39th Biennial Session - Berlin, Germany (19 - 23 May, 2014)



FRANCE

CONSEIL ÉLEVAGE Donner du sens à la mesure

Challenges and requests

Maintain a high penetration rate

A PARTY ASSA

- To ensure a selection base as wide as possible
- To collect classical and new traits (fatty acids,...)

Maintain a sufficient quality for genetic evaluation

Develop new milking schemes

- To reduce costs of milk recording
- To limit the constraints of milk samples collection
- To improve flexibility by different approaches (increase or decrease of recording intervals, length of sampling period...)



3 studies have been realised between 2003 and 2013

www.idele.fr ICAR 39th Biennial Session - Berlin, Germany (19 - 23 May, 2014)



Donner du sens à la mesu

Datasets used (1)

Dataset 1 : AT and CZ schemes from A1 method

-Data were collected on one experimental farm -Daily registration of morning / evening milk (+ sample collection one day per week) (13 574 TD on 290 cows with a milking interval of 10/14 hours)

- Cows were registered during a long period (complete lactation)

Dataset 2 : AT and CZ schemes with and without adjustments from A4/A5 methods

-Data were collected on 286 commercial farms with lactocorder -Morning / evening sampling analysed separately (89 828 TD on 18 101 cows)

- Individual milking times

ATTACK ASTR

www.idele.fr ICAR 39th Biennial Session - Berlin, Germany (19 - 23 May, 2014)



CONSEIL ÉLEVAGE Donner du sens à la mesure

Datasets used (2) and average performance

Dataset 3 : Reduce the sampling period to 12 hours on robotic scheme

-Data were collected on 268 commercial farms with AMS -52 361 TD from 19 783 cows

With all samples collected on 12 hours sampling period

Average yield performance

A PARTY ASTOC

	Dataset 1	Dataset 2	Dataset 3	
Specificity	Lactation study	EMM with milking time	Robotic Milking	
Mean Milk (kg)	20.1	27.9	26.9	
Mean Fat (kg)	0.850	1.116	1.084	
Mean Protein (kg)	0.659	0.901	0.873	





CONSEIL ÉLEVAGE

Methods used for adjustment on dataset 2



- used the adjustments estimated as proposed by Liu and al (2000) for milk, fat and protein (yield)
- considering separate regressions for every combination of parity *i*, milking interval *j*, lactation stage *k* :

 $y_{ATadjust.}$ [*ijk*] = b_0 [*ijk*] + b_1 [*ijk*] y_{AT} [*ijk*]

For CZ model :

extension of the AT adjustments for fat and protein (yield) by including the other milking of a test-day as covariate for
 Morning: y_{Adjust} ^[ijk] = b₀ ^[ijk] + b₁^[ijk] y_{AT-am} ^[ijk] + b₂^[ijk] Milk_{-pm} ^[ijk]
 Evening: y_{Adjust} ^[ijk] = b₀ ^[ijk] + b₁^[ijk] y_{AT-pm} ^[ijk] + b₂^[ijk] Milk_{-am} ^[ijk]

On both case : 2 parity (first vs 2nd and later) 5 milking interval (of 30 minutes) 12 lactation stage (of 30 days)

www.idele.fr ICAR 39th Biennial Session - Berlin, Germany (19 - 23 May, 2014)

CONSEIL ÉLEVAGE

Results : Impact of proposed milking schemes on the *daily* yield







www.idele.fr ICAR 39th Biennial Session - Berlin, Germany (19 - 23 May, 2014)

A PAR ASTO

Correlation (R²) between A reference and estimated daily yields

		Milk		Fat		Protein		
Scheme	Dataset	Adjust.	АМ	РМ	АМ	РМ	АМ	РМ
AT	1	No	0.955	0.908	0.802	0.824	0.949	0.897
AT	2	No	0.939	0.914	0.865	0.863	0.928	0.902
AT	2	Yes	0.959	0.940	0.894	0.874	0.952	0.933
CZ	1	No			0.856	0.932	0.996	0.996
CZ	2	No			0.903	0.896	0.993	0.990
CZ	2	Yes			0.931	0.916	0.994	0.991
R	3	No			0.965		0.995	



FRANCE

CONSEIL ÉLEVAGE Donner du sens à la mesure

www.idele.fr ICAR 39th Biennial Session - Berlin, Germany (19 - 23 May, 2014)

ALTER ATTACK

Summary of results on the daily yield

CZ scheme increases accuracies vs AT

on milk, fat and protein yields in comparison with AT

schemes

ALL ALL ALL ALL ALL

- milk is 1.00 by construction and protein is over than **Adjusted scheme increases accuracies**

For AT scheme :

- on milk, fat and protein yields
- but the accuracy remains lower than 0.90 for fat yield

For CZ scheme :

on fat yield (accuracy is greater than 0.91 for fat yield)

With robot milking, the accuracy level is acceptable

- higher than 0.96 for fat yield
 - higher than 0.99 for protein yield



Donner du sens à la mesur

Results : Impact of proposed milking schemes on the *lactation* yield







A PARA ASTIC

13

Number of milk recording necessary to reach R² of 0.95 and 0.98 between a tested milking scheme and A4 reference one

			Milk		Fat		Protein	
Scheme	Datase t	1 st recording	R²		R ²		R ²	
			0.95	0.98	0.95	0.98	0.95	0.98
AT	1	AM	2	4	7	Never	2	5
AT	1	PM	2	4	5	Never	3	6
CZ	1	AM			3	7	1	1
CZ	1	PM			2	6	1	1



FRANCE

CONSEIL ÉLEVAGE Donner du sens à la mesure

www.idele.fr ICAR 39th Biennial Session - Berlin, Germany (19 - 23 May, 2014)

A STAR ASTA

Summary of results on the lactation yield estimation

With AT scheme :

A PAR ARA

- high level of correlation (0.98) are reached quickly for milk yield
- for protein yield, the situation is worse than milk yield
- for fat yield, 5 or 7 test-day are needed to reach R² of 0.95

With CZ scheme :

for protein yield, the first recording is sufficient to reach R² of 0.98
for fat yield, 2 or 3 monthly test-day are needed to reach R² of 0.95, 6 or 7 test-day for 0.98.

The comparison of AT and CZ shows a clear advantage of recording milk yield on 24 hours to improved the estimation of fat and protein yields

15

CONSEIL ÉLEVAGE Donner du sens à la mesure

www.idele.fr ICAR 39th Biennial Session - Berlin, Germany (19 - 23 May, 2014)

Conclusion

These French studies show that:

A PRIME ASTR

- CZ scheme is an alternative between A scheme and AT scheme
- Adjustment in AT and CZ schemes improve the accuracy
- Robot scheme is less accurate than A scheme for fat yields

The schemes developed since the last 10 years allowed:

- to maintain a high rate penetration of milk recording
- to reduce the cost of milk recording
- the progression of "low demanding" schemes

There are alternative solutions to A scheme. Alternate schemes with adjustments (AT, CZ) are interesting ways that meet the needs of farmers, technical support and genetic evaluation.

www.idele.fr ICAR 39th Biennial Session - Berlin, Germany (19 - 23 May, 2014)



CONSEIL ÉLEVAGE Donner du sens à la mesure

Thank you for your attention



17

www.idele.fr ICAR 39th Biennial Session - Berlin, Germany (19 - 23 May, 2014)

ALL AND AND ASSAULT